






knives . ancillary items . sharpening steels . grinding machines www.dick.de

Premier Nature

The Natural



Care instructions:

Due to their wooden handle, these knives are not dishwasher proof. Besides, knives generally should not be cleaned in a dishwasher. Otherwise, the precisely polished edge would be affected.

We recommend cleaning the knives under running water with a soft cloth and a mild cleaning agent. The knife should be carefully wiped dry after cleaning in order to avoid spots on the blade.

The handle should be cared for separately:

A hint of almond or olive oil adds a fine protection and maintenance film to the handle.

F. DICK premium knife series:

